TLC60 REMOTE CONTROL

The remote control allows the remote piloting and selection of various settings of the ATEQ range of devices. This remote control is to be connected to the Input/Output connector.

4 functions:

- → Reset and cycle start
 → Incrementing or decrementing program numbers
- → Display of the selected programme number
- → Test result display, green light for good part, red light for bad part or alarm

Note: changing the programme number (incrementing or decrementing) can only be done outside a control cycle.



On power-up, as long as the "End of cycle" information is not present, the TLC60 remote control alternately displays its programme version and the indicator tests.







